


**IMPORTANT SAFE GUARDS:**

- THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODE BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED.
- DISCONNECT POWER BEFORE BEGINNING INSTALLATION.
- FIXTURE MUST BE INSTALLED IN COMPLIANCE WITH THE NATIONAL ELECTRIC CODE AND ANY LOCAL CODES.
- TO BE INSTALLED ONLY BY A QUALIFIED ELECTRICIAN.
- PROPER GROUNDING IS REQUIRED TO INSURE PERSONAL SAFETY.
- READ ALL FIXTURE MARKINGS AND LABELS TO ENSURE CORRECT INSTALLATION OF FIXTURE.
- RISK OF FIRE, USE A MINIMUM OF 90C SUPPLY CONNECTORS.


**INSTALLATION INSTRUCTIONS:**

1. Remove door frame fasteners.


**GRID COMPATIBILITY:**

Spaced at 1x2 - 12" x 24" Center to Center  
Spaced at 1x4 - 12" x 48" Center to Center  
Spaced at 2x2 - 24" x 24" Center to Center  
Spaced at 2x4 - 24" x 48" Center to Center


2. Remove LED gear tray.



3. Raise fixture into grid ceiling.  
Adjust as necessary to center.



4. After making necessary electrical connections, reattach LED gear tray.



5. Reattach frame.

